

Scan and send a document

1. From Scanning home page, insert paper—face down.
Scanner pulls paper in approximately ½ inch. If less than 8½ inches wide, align with right edge so that small tooth in slot is covered.
2. Choose the Document Type from pull-down menu.
3. Check the **Preview** box if you would like to preview the scanned page before sending. Tap **Scan Page**.
4. After page goes through, tap **Done**.
To send up to five documents at a time, insert next sheet and tap **Add Page**.
If desired, enter a comment before sending document(s).
5. Tap **Send** and then **OK** to confirm your choice.

RMA Authorization Process

- For initial support, call Omnitrac's Customer Support at (800) 541-7490.
- If you want to follow up on an RMA for status and have already received an RMA number from Quest Solution, contact:

Quest Solution

(714) 899-4800

<https://omnitrac.questsolution.com/q/mobileprinters/default.aspx>

Omnitrac, LLC
717 N. Harwood Street, Suite 1300
Dallas, TX 75201 U.S.A.

© 2009-2011, 2013, 2015-2016 Omnitrac, LLC. All rights reserved.
Omnitrac is a trademark of Omnitrac, LLC. All other trademarks are the property of their respective owners.
Omnitrac endeavors to ensure that the information in this document is correct and fairly stated, but Omnitrac is not liable for any errors or omissions. Published information may not be up to date, and it is important to confirm current status with Omnitrac.
This technical data may be subject to U.S. and international export, re-export or transfer (export) laws. Diversion contrary to U.S. and international law is strictly prohibited.

80-JB531-1 Rev. F
September 2016

Scan and send a document

1. From Scanning home page, insert paper—face down.
Scanner pulls paper in approximately ½ inch. If less than 8½ inches wide, align with right edge so that small tooth in slot is covered.
2. Choose the Document Type from pull-down menu.
3. Check the **Preview** box if you would like to preview the scanned page before sending. Tap **Scan Page**.
4. After page goes through, tap **Done**.
To send up to five documents at a time, insert next sheet and tap **Add Page**.
If desired, enter a comment before sending document(s).
5. Tap **Send** and then **OK** to confirm your choice.

RMA Authorization Process

- For initial support, call Omnitrac's Customer Support at (800) 541-7490.
- If you want to follow up on an RMA for status and have already received an RMA number from Quest Solution, contact:

Quest Solution

(714) 899-4800

<https://omnitrac.questsolution.com/q/mobileprinters/default.aspx>

Omnitrac, LLC
717 N. Harwood Street, Suite 1300
Dallas, TX 75201 U.S.A.

© 2009-2011, 2013, 2015-2016 Omnitrac, LLC. All rights reserved.
Omnitrac is a trademark of Omnitrac, LLC. All other trademarks are the property of their respective owners.
Omnitrac endeavors to ensure that the information in this document is correct and fairly stated, but Omnitrac is not liable for any errors or omissions. Published information may not be up to date, and it is important to confirm current status with Omnitrac.
This technical data may be subject to U.S. and international export, re-export or transfer (export) laws. Diversion contrary to U.S. and international law is strictly prohibited.

80-JB531-1 Rev. F
September 2016

Mobile Computing Platform 100 (MCP100) In-Cab Scanning Installation Instructions, 468Q



- Getting Started
- Installation Checklist
- Step-by-Step Instructions
- Calibration
- Scanning and Sending
- RMAs

WARNING

Driver – Do not use while vehicle is in motion.
Use while driving will cause distraction and loss of vehicle control which may lead to serious injury or death.

Mobile Computing Platform 100 (MCP100) In-Cab Scanning Installation Instructions, 468Q



- Getting Started
- Installation Checklist
- Step-by-Step Instructions
- Calibration
- Scanning and Sending
- RMAs

WARNING

Driver – Do not use while vehicle is in motion.
Use while driving will cause distraction and loss of vehicle control which may lead to serious injury or death.

Getting Started

Installation Steps

The following parts list consists of the items included in the **65-JB526-1** or **65-JB526-2 in-cab scanner kit**. Use these numbers to re-order additional parts.

Scanner P/N 825-53392-1468

Scanner Cable P/N 364-53896-0000

Holster (optional) P/N 825-53392-0002
(included in 65-JB526-1 kit only)



WARNING

Mounting the scanner near the vehicle airbags can injure a driver or passenger involved in a crash.

Airbag firing can cause the scanner to become a projectile leading to serious injury or death.

Mount the scanner in a location that will not be impacted by the firing of any forward or side airbag.

Improper cable installation can interfere with the vehicle pedals or steering.

Interfering with the pedals or steering can cause a crash, resulting in serious injury or death.

Mount the cables so that they can not interfere with the brake, accelerator, clutch, or steering wheel, **EVEN IF THE TIE WRAPS FAIL.**

Installation Checklist

- Move unit into iQ Operational Profile with scanning (one time only).
- Install hardware in desired location using the Dual Lock tape or holster option.
- Calibrate scanner.
- Scan and send a document.
- Check the scanning outbox to make sure it was sent.
- Provide training for drivers and tell them to call their Driver Manager or Omnictracs Customer Support at (800) 541-7490 for support.

MAY CONTAIN U.S. AND INTERNATIONAL EXPORT CONTROLLED INFORMATION

1 Connect the scanner

1. Remove metal cover from MAS USB/SER connector.
2. Select scanner location.
3. Insert B Connector of USB cable into scanner and A Connector into available MAS USB port.
4. If mounting scanner only, **see step 2a**.
If mounting holster to stow scanner, **see step 2b**.
5. Route scanner cable so it will not be damaged, obstruct driver, or hinder truck performance. **Note:** Route cable under wells and interior molding if needed.

2a Mount the scanner directly—no holster (65-JB526-2)

1. Confirm scanner location.
2. Clean scanner bottom and mounting surface with alcohol pad and let dry.
3. Remove backing from two pieces of Dual Lock Tape and apply to bottom ends of scanner.
4. Remove backing from two other pieces of tape and apply to mounting surface.
5. Position scanner in desired location and press firmly to secure grip of tape.

2b Mount a holster to stow the scanner (65-JB526-1)

1. Select holster location.
2. Clean mounting surface with alcohol pad and let dry.
3. Remove backing from Dual Lock Tape on holster.
4. Position holster in desired location and press firmly to ensure surface contact.
Optional: Self-drilling screws can be installed for more support.

3 Calibrate the scanner

1. From MCP100 home screen, tap **Scanning**.
2. From Scanning home screen, tap **Options**.
3. Insert black and white calibration page (or plain white sheet of paper) into scanner until engaged.
4. Tap **Calibrate**. When paper finishes moving through scanner, tap **Scan** to return to Scanning home screen.

Note: Calibrate and clean the scanner once per month.

Getting Started

Installation Steps

The following parts list consists of the items included in the **65-JB526-1** or **65-JB526-2 in-cab scanner kit**. Use these numbers to re-order additional parts.

Scanner P/N 825-53392-1468

Scanner Cable P/N 364-53896-0000

Holster (optional) P/N 825-53392-0002
(included in 65-JB526-1 kit only)



WARNING

Mounting the scanner near the vehicle airbags can injure a driver or passenger involved in a crash.

Airbag firing can cause the scanner to become a projectile leading to serious injury or death.

Mount the scanner in a location that will not be impacted by the firing of any forward or side airbag.

Improper cable installation can interfere with the vehicle pedals or steering.

Interfering with the pedals or steering can cause a crash, resulting in serious injury or death.

Mount the cables so that they can not interfere with the brake, accelerator, clutch, or steering wheel, **EVEN IF THE TIE WRAPS FAIL.**

Installation Checklist

- Move unit into iQ Operational Profile with scanning (one time only).
- Install hardware in desired location using the Dual Lock tape or holster option.
- Calibrate scanner.
- Scan and send a document.
- Check the scanning outbox to make sure it was sent.
- Provide training for drivers and tell them to call their Driver Manager or Omnictracs Customer Support at (800) 541-7490 for support.

MAY CONTAIN U.S. AND INTERNATIONAL EXPORT CONTROLLED INFORMATION

1 Connect the scanner

1. Remove metal cover from MAS USB/SER connector.
2. Select scanner location.
3. Insert B Connector of USB cable into scanner and A Connector into available MAS USB port.
4. If mounting scanner only, **see step 2a**.
If mounting holster to stow scanner, **see step 2b**.
5. Route scanner cable so it will not be damaged, obstruct driver, or hinder truck performance. **Note:** Route cable under wells and interior molding if needed.

2a Mount the scanner directly—no holster (65-JB526-2)

1. Confirm scanner location.
2. Clean scanner bottom and mounting surface with alcohol pad and let dry.
3. Remove backing from two pieces of Dual Lock Tape and apply to bottom ends of scanner.
4. Remove backing from two other pieces of tape and apply to mounting surface.
5. Position scanner in desired location and press firmly to secure grip of tape.

2b Mount a holster to stow the scanner (65-JB526-1)

1. Select holster location.
2. Clean mounting surface with alcohol pad and let dry.
3. Remove backing from Dual Lock Tape on holster.
4. Position holster in desired location and press firmly to ensure surface contact.
Optional: Self-drilling screws can be installed for more support.

3 Calibrate the scanner

1. From MCP100 home screen, tap **Scanning**.
2. From Scanning home screen, tap **Options**.
3. Insert black and white calibration page (or plain white sheet of paper) into scanner until engaged.
4. Tap **Calibrate**. When paper finishes moving through scanner, tap **Scan** to return to Scanning home screen.

Note: Calibrate and clean the scanner once per month.